

$$DS = 1.000 \text{ DS}$$

$$FC = 0.060 \text{ DS}$$

$$CP = 1.060 \text{ DS} = 0.985 \text{ CD}$$

$$FS = 0.015 \text{ CD} = 0.016 \text{ DS}$$

$$CD = 0.800 \text{ PVHT} = 1.076 \text{ DS}$$

$$FG = 0.120 \text{ PVHT}$$

$$CR = 0.920 \text{ PVHT}$$

$$BA = 0.080 \text{ PVHT}$$

$$PVHT = 1.345 \text{ DS}$$

$$\text{Si } CP = DS + FC$$

$$\text{Alors } CP = 1.000 \text{ DS} + 0.060 \text{ DS} = 1.060 \text{ DS}$$

$$\text{Si } CR = PVHT - BA$$

$$\text{Alors } CR = 1.000 \text{ PVHT} - 0.080 \text{ PVHT} = 0.920 \text{ PVHT}$$

$$CD = CR - FG = 0.920 \text{ PVHT} - 0.120 \text{ PVHT} = 0.800 \text{ PVHT}$$

$$\text{Si } CP = CD - FS$$

$$\text{Alors } CP = 1.000 \text{ CD} - 0.015 \text{ CD} = 0.985 \text{ CD}$$

$$0.985 \text{ CD} = 1.060 \text{ DS}$$

$$0.015 \text{ CD} = ? \text{ DS}$$



$$\text{Alors } FS = 0.015 \times 1.060 / 0.985 = 0.016 \text{ DS}$$

$$CD = 0.800 \text{ PVHT} = CP + FS = 1.060 \text{ DS} + 0.016 \text{ DS} = 1.076 \text{ DS}$$

$$0.800 \text{ PVHT} = 1.076 \text{ DS}$$

$$1.000 \text{ PVHT} = ? \text{ DS}$$



$$1.000 \times 1.076 / 0.800 = 1.345 \text{ DS}$$